

The Camperman Australia Travel Pack includes:


- Towels, Sheets, Sleeping bags, Pillows, Tea towels, Linen
- Can Opener, Carving Fork, Egg Lifter, Ladle, Cutting Board, Tongs, Forks, Knives, Spoons, Tea Spoons, Cereal Bowls, Cups, Glasses, Side Plates, Dinner plates, Micro Dishes, Saucepans, Frying Pan, Kettle, clothes hangers.
- Maps, camping ground guides and special camp discount privileges

Specifications

- 2.0L and 2.4L Unleaded Petrol
- 4 Cylinder Engine
- 5 Speed Manual Transmission
- Fuel Tank Capacity: Approx. 60L
- Fuel Consumption: Approx. 14L Per 100km
- Vehicle Exterior Dimensions:
- Length: 5.0m, Height: 2.6m, Width: 1.7m
- Interior Height: 1.9m
- SUITABLE FOR 2 - 3 PERSONS

Features

- Air conditioned cabin
- Cabin seats 3 people
- Cigarette lighter suitable for recharging camera batteries
- AM/FM radio & cassette
- Dinette that converts to double bed
- Double bed: 1.9m long by 1.5m wide fixed roof
- Storage area under benches
- Storage area
- 40 litre water tank
- 2 burner gas stove with grill
- 1 burner gas stove
- Dual battery system
- Fire extinguisher
- Fridge 55L (12v/240v)
- 12v/240v lighting
- 240v power sockets



Jesse Toyota Hiace Hightop Campervan Specifications: Manufactured in 1998 and 2000

4 cylinders, 2.4 litre unleaded petrol motor, 5 speed manual transmission. Fuel tank capacity 60 litres. Average fuel consumption at 100kms average is 14 litres per 100kms. Fuel economy will go to 20-23litres per 100kilometres. Engine oil: Multigrade 20W 50.

You will notice that the radiator cap is locked down. Please check the water through the plastic water bottle behind and under the driver's seat. Every third day when getting the fuel filled ask the service station attendant to check the level of water and coolant in the radiator. Most clients have trouble putting the radiator cap back on a hot motor. So please do not attempt it yourself.

The tyre pressure must be checked daily. The recommended tyre pressure for these vehicles are, front: 45psi (310kPa), rear: 45psi (310kPa).

The spare wheel is located under the rear of the vehicle and is only accessible from the outside of the vehicle, behind the rear bumper.

The tools required for changing your spare wheel (plus limited hand tools) including the jack are in the compartment near the step just inside the sliding door on the side of the van.

The cab chassis air conditioner works solely off the motor when it is running. The engine should not be left to run at idle to run this air conditioner.

Suitable for 2-3 persons. Cabin seats 3 people. AM/FM radio & cassette player. Dual battery system. Storage under seats. Dinette converts to double bed, 1.9m long by 1.7 wide.

Bed in roof has a 17mm bed base board that's capable of holding a 97kg person who 187cm tall. We suggest a person of 187cm tall who weighs 80 kgs will be very comfortable in this bed.

The water tank holds 45 litres of fresh water. The container is located under the driver's side of the van. This container is not removable. The filler cap is located on the right side, beside the gas bottle compartment. The filler hose is located inside the vehicle. (Fill the tank slowly to let the air escape from the tank.

The vans are normally fitted with a manual hand pump. If the van is fitted with a pressurized pump make sure the pump is turned off at the switch when not in use.

The gas cooker has two burners on the top and one burner for a griller. Ignition is with a match. The gas turns to high and low. Make sure that the gas is turned off after cooking and not just turned to low.

The gas bottle is located in the gas bottle locker on the outside of the campervan. Please ensure that the gas is turned off when you are travelling. For safety turn the gas off at the bottle. Gas bottles can be filled at most gas stations as well as most camping sites.

The 55 litre fridge operates on dual power, 12 volt and 240 volt. The fridge will automatically turn from 12 volt to 240 volt when the van is plugged into external 240 volt power. To operate on 240 volt the van must be connected to a 240volt supply. The fridge should be turned on whilst driving.

There is a 240 volt light in the rear. There are 2 12 volt lights in the campervan.

Each vehicle is equipped with a fire extinguisher - Strictly for the use in cases of emergency. If they are discharged for any reason you will be held accountable. Please tell us if the fire extinguisher has been used so it can be refilled.